

Garbing

Prior to Entering the Anteroom or Segregated Compounding Area



1. Remove outer garments, jewelry, cosmetics.



2. Don clean, low-shedding clothing (e.g. scrubs)



3. Perform routine hand hygiene using soap and water or alcohol based hand rub.

In Anteroom or Upon Entry to Segregated Compounding Area



4. Don head cover and beard cover, if required, ensuring all hair is covered.



5. Don face mask ensuring coverage from the bridge of the nose to the area under the chin.



6. Apply shoe covers one at a time while stepping over the line of demarcation. A second pair of shoe covers should be donned if entering the hazardous cleanroom.



7. Perform Hand Hygiene using
Step 1: Initial Scrub with SOAP for 30-60 secs.



8. Don a disposable or reusable gown that closes at the neck and has elastic cuffs.



For Hazardous drugs, don a disposable gown that resists permeability.

On Clean Side of Anteroom or Upon Entry to the Cleanroom



9. Open the outer wrapper of the sterile glove package onto a clean surface, exposing the inner glove package.



10. Apply ABHR with persistent activity to all surfaces of forearms, lower gown sleeves, then apply rub to hands and fingers. Allow hands to dry completely.



11. Don sterile gloves. For Hazardous drugs, don 2 pairs of sterile chemotherapy gloves. 1st glove is under and 2nd glove is over the gown's cuff.